


Setting Up Shutter Delay / Mirror Up

IS Pro
UV/IR

Shutter Delay and Mirror-Up mode are useful for long exposures in reducing camera shake.

1. Exposure Delay provides a very short delay before the image is take. To turn on, access the Setup / SHOOTING menu in tab one.
2. Access the “EXPOSURE DELAY MODE” and turn it on.
3. A longer delay can be obtained buy turning on the Mirror-Up mode (Mup).

The first cycle of the shutter button lifts the mirror and the second cycle takes the picture. (Suggest using a Nikon cable release)



FUJIFILM