

***Pro Lab Technical Service Bulletin***

**Bulletin Reference:** *CLP 008*

**Date:** *January 1, 2005*

**Topic:** *Light Jet Recommended Values*

The following are the recommended aim values for Fujicolor materials on the LightJet 5000, 430, and 500XL.

Access the OCE website to download the self-extracting targets.

[http://www.oce-dgs.com/PrinterSupport/LJ\\_Customer\\_Access/LJ\\_Customer\\_Access.htm](http://www.oce-dgs.com/PrinterSupport/LJ_Customer_Access/LJ_Customer_Access.htm)



**REPLACES current CDII and PDII**

*Fuji Crystal Archive Paper Super Type C and Super Type PD* Rev A *All Developers*  
*(emulsion 126~)* *(emulsion 989~)*

Dmin R	Dmin G	Dmin B	Dmax R	Dmax G	Dmax B
.09	.09	.06	2.52	2.42	2.35

*Fuji Crystal Archive Paper CDII and PDII* Rev B *All Developers*

Dmin R	Dmin G	Dmin B	Dmax R	Dmax G	Dmax B
.09	.09	.06	2.52	2.42	2.32

*Fuji Crystal Archive FujiClear\** Rev. B *Standard Developer*

Dmin R	Dmin G	Dmin B	Dmax R	Dmax G	Dmax B
.04	.05	.04	2.84	2.85	2.86

\* Development time= 1 minute 50 seconds    Densities measured with Status A Transmission densitometer filters

*Fuji Crystal Archive FujiClear\** Rev. A *Digital Developer*

Dmin R	Dmin G	Dmin B	Dmax R	Dmax G	Dmax B
.04	.05	.04	3.25	3.20	3.07

\* Development time= 1 minute 50 seconds    Densities measured with Status A Transmission densitometer filters

**Pro Lab Technical Service continued**

Bulletin Reference: **CLP 008**

Date: **January 1, 2005**

Topic: **Light Jet Recommended Values**

*Fuji Crystal Archive FujiTrans\* for Digital Printing* Rev A

*All Developers*

Dmin R	Dmin G	Dmin B	Dmax R	Dmax G	Dmax B
.38	.40	.40	3.25	3.25	3.35

\* Development time= 1 minute 50 seconds    Densities measured with Status A Transmission densitometer filters



**REPLACES current Crystal Archive Fujiflex**

*Fujiflex CA Printing Material Type II for Digital Printing (emulsion U01~)* Rev A

*For LightJet 430/500XL Only*

*All Developers*

Dmin R	Dmin G	Dmin B	Dmax R	Dmax G	Dmax B
.08	.09	.07	2.60	2.55	2.40

*Fujiflex CA Printing Material Type II for Digital Printing (emulsion U01~)* Rev B

*For LightJet 5000 Only*

*All Developers*

Dmin R	Dmin G	Dmin B	Dmax R	Dmax G	Dmax B
.09	.09	.06	2.50	2.42	2.37

*Fuji Crystal Archive FujiFlex (emulsion V01~)* Rev A

*All Developers*

Dmin R	Dmin G	Dmin B	Dmax R	Dmax G	Dmax B
.08	.08	.08	2.55	2.40	2.35